

In Situ and Operando Characterization of Lithium-ion Electrodes Using Transmission X-ray Microscopy

Jesse S. Ko and Johanna Nelson Weker*

Stanford Synchrotron Radiation Lightsource, SLAC National Accelerator Laboratory, Menlo Park, CA


Space Power Workshop
Energy Storage III— Advanced Energy Storage Topics
Torrance, CA
4 April 2019




- ❑ Background and motivation
- ❑ Cathode: Lithium cobalt oxide (LiCoO_2)
- ❑ Anode: Tin (Sn)
- ❑ “Beyond Li-ion”
- ❑ Conclusions
- ❑ Acknowledgements

Background and motivation


- ❑ Li-ion batteries currently dominate the energy storage landscape (on Earth)
- ❑ Space applications require higher tolerance to extreme operating conditions:
 - ✓ Light weight & compact
 - ✓ Gravity
 - ✓ Operate under extreme temperatures (-120°C to 475°C)
 - ✓ Long calendar life
 - ✓ Tolerance to high levels of radiation
 - ✓ Safe




Winter et al., Chem. Rev., 118 (2018)









Stanford Synchrotron Radiation Lightsource (SSRL)



X-ray interactions with matter



Characterization across multiple length scales




1. Unpublished results from APS on an 18650 cell
2. Nelson Weker et al, *ChemElectroChem*, 2 (2015)
3. Wise et al. *ACS Catal.*, 6 (2016)
4. Cao et al, *Nano Lett.*, 16 (2016)

Transmission X-ray microscopy @ BL6-2c


SLAC



X-ray microscopy provides nondestructive, high resolution X-ray images




- ❑ Fast: ½ sec imaging
- ❑ ~30 nm resolution imaging
- ❑ ~30 μm field of view (mosaic mode)
- ❑ thick samples \rightarrow *in situ* samples
- ❑ elemental/chemical mapping (~5 – ~13 keV)
 - ❑ Ni, Mn, Co, Fe, and Zn
- ❑ tomography (~50 nm resolution)



Comparison to other complementary techniques


Plot of various *in situ* imaging techniques for energy storage and type of cells.






As imaging resolution is improved to study finer structures, the required modifications to the *in situ* cell take it further from a realistic commercial battery architecture

- ❑ Background and motivation
- ❑ Cathode: Lithium cobalt oxide (LiCoO_2)
- ❑ Anode: Tin (Sn)
- ❑ “Beyond Li-ion”
- ❑ Conclusions
- ❑ Acknowledgements




Commercial cathode material: LiCoO_2



$\sim 135 \text{ mAh g}^{-1}$ reversible capacity ($\sim 0.5 \text{ Li}^+$)



Operando XANES of deep discharge of LiCoO₂




Agrees with capacity (~2.6 Li⁺) and operando X-ray diffraction

Deep discharge of LiCoO_2

Incomplete transformation to Co metal:

- Core/shell: Core remains LiCoO_2
- Disconnected particles remain LiCoO_2

Nelson Weker et al., Electrochim. Acta, 247 (2017)



- ❑ Background and motivation
- ❑ Cathode: Lithium cobalt oxide (LiCoO_2)
- ❑ Anode: Tin (Sn)
- ❑ “Beyond Li-ion”
- ❑ Conclusions
- ❑ Acknowledgements

Porous anodes for high capacity and high cycle life

Mechanism	Pros	Cons	Example (Specific Capacity)
Intercalation	Maintains Structure	Low Capacity	Graphite (372 mAh g ⁻¹)
Alloy	High Capacity	Volume Expansion	Tin (960 mAh g ⁻¹)

Bulk



↓ Li⁺ in



Cracking and Pulverization


Nanoparticles



↓ Li⁺ in




↓ Li⁺ out



Lose contact with conductive matrix and current collector

Selective dealloying – facile method to form porous networks



- More Noble Metal
- Sacrificial Metal



Acid/Base ↓




Nanoporous Sn



- Nanoporous Sn (NP-Sn) with ~25% internal porosity
- High capacity alloying anodes undergo large volume changes during cycling resulting in cracking/pulverization
- Nanoporosity can reduce volume changes to avoid irreversible deformation and extend battery lifetime

Visualizing volume changes in dense and porous Sn


Lithiation



Dense Sn

NP-Sn


Delithiation



Dense Sn

NP-Sn

Visualizing volume changes in dense and porous Sn



- End of Li⁺ insertion leads to burst expansion of dense Sn
- Crack formation in dense Sn
- Porous Sn 6× smaller areal expansion

- ❑ Background and motivation
- ❑ Cathode: Lithium cobalt oxide (LiCoO_2)
- ❑ Anode: Tin (Sn)
- ❑ “Beyond Li-ion”
- ❑ Conclusions
- ❑ Acknowledgements

Odyssey of Multivalent Cathode Materials: Open Questions and Future Challenges

Pieremanuele Canepa,^{*,†,‡,§,||} Gopalakrishnan Sai Gautam,^{†,‡,§,||} Daniel C. Hannah,^{†,||} Rahul Malik,[‡] Miao Liu,^{||} Kevin G. Gallagher,[‡] Kristin A. Persson,^{||} and Gerbrand Ceder^{*,†,‡,§}


[†]Materials Science Division, Lawrence Berkeley National Laboratory, Berkeley, California 94720, United States

[‡]Department of Materials Science and Engineering, Massachusetts Institute of Technology, Cambridge, Massachusetts 02139, United States



[§]Department of Materials Science and Engineering, University of California Berkeley, California 94720, United States

^{||}Energy and Environmental Science Division, Lawrence Berkeley National Laboratory, Berkeley, California 94720, United States

[‡]Chemical Sciences and Engineering, Argonne National Laboratory, Lemont, Illinois 60439, United States




Confirm phase-pure NVP particles @ BL11-3



Rhombohedral $R\bar{3}c$ space group

$a = b = 8.7 \text{ \AA}$


$c = 21.8 \text{ \AA}$



● Na1 & Na2

▮ VO₆

▴ PO₄



Operando XRD (@ SSRL BL11-3) shows qualitative changes during charge/discharge





Electrolyte:
0.5 M Zn Acetate

Counter:
Zn foil (0.25 mm)/4 mm hole in center




Separator:
Whatman
glass fiber

Electrode (70/20/10):
NVP/SuperP/PVDF
coated on Al foil
mass loading: 1 mg cm⁻²



Conclusions

- ❑ Transmission X-ray microscopy enables high resolution *operando* visualization of battery materials nondestructively
- ❑ Tracked the chemistry of LiCoO_2 particles by mapping Co oxidation states when cycled outside standard operating conditions
- ❑ Understood the benefits of 3D porous morphology on volume expansion anode material (Sn)
- ❑ Investigating multivalent charge storage based on Zn^{2+} insertion/de-insertion of $\text{Na}_3\text{V}_2(\text{PO}_4)_3$



TXM at beamline 6-2c (SSRL)

Acknowledgements

Thank you for your attention and time



Johanna
Nelson
Weker



Michael
Toney



Partha Paul



Natalie
Seitzman



Kipil Lim



U.S. DEPARTMENT OF
ENERGY

Office of Science



UCLA



Sarah
Tolbert



John Cook



Terri Lin



Andrew
Dawson

